




DRAENERT



**MONTAGE
ASSEMBLY**

1132 INTERMEZZO

ASSEMBLY

1132 INTERMEZZO

CONTENT OF DELIVERY


(remains with the customer)

- 1 x pedestal with 3 base tubes
- 3 x brass or chrome rings
- 3 x glass tops with each a pivoting tube (different sizes)
- 2 x push rods
- plastic glides
- material information




PERSONS REQUIRED FOR ASSEMBLY: 1 PERSON


Place the glass base on a trestle or a higher substructure.




1 | The pedestal is already pre-assembled. First put the three metal rings on the base tubes. Insert on the lowest base tube the smallest glass top.



2 | Insert the medium size glass top on the medium high base tube.



3 | Insert the biggest size glass top on the highest base tube.



4 | Pivot the glass tops to one another, then the push rods can be inserted with the joints into the borings of the pivoting tubes.

Now the table is ready assembled.

OPERATION

By pivoting the upper glass top anti-clockwise, the smaller inferior glass tops swing out synchronously (see picture 4).

Further information on the back side.

LIABILITY EXCLUSION FOR GLASS TABLES

The glass base plates are part of the design. Scratches to the glass base plates are unavoidable and, therefore, complaints cannot be accepted. As necessary please adhere PVC glides.

CARE

The table is maintenance-free. For cleaning the glass plates you may order with us an according cleaning and care agent for high-quality glass surfaces. Kindly pay attention to the material information.

INSTRUCTIONS FOR MOVING THE TABLE

For moving the table, please pay attention that the table may only be carried (lifted) on the base plate or at its base tubes.

REMOVAL

For removal, disassemble the table in reverse order of the assembly.

DRAENERT GMBH

STEIGWIESEN 3
88090 IMMENSTAAD / BODENSEE
GERMANY

FON +49 (0) 7545 - 2080

info@draenert.de

www.draenert.de

STAND 10/2015